



THE NEW
BLADE
125i

OWNER'S MANUAL

•WARRANTY POLICY



ACB125CBF/CBT

*14 Point Free Check-Up

REGISTER NOW!!!
FOR A HASSLE FREE
WARRANTY

This manual should be considered a permanent part of the scooter and should remain with the scooter when it is resold.

This publication includes the latest production information available before printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation.

No part of this publication may be reproduced without written permission.

The vehicle pictured in this owner's manual may not match your actual vehicle.

Welcome

Congratulations on your purchase of a new Honda scooter. Your selection of a Honda makes you part of a worldwide family of satisfied customers who appreciate Honda's reputation for building quality into every product.

To ensure your safety and riding pleasure:

- Read this owner's manual carefully.
- Follow all recommendations and procedures contained in this manual.
- Pay close attention to safety messages contained in this manual and on the scooter.

- The following codes in this manual indicate each country.
- The illustrations here in are based on the ACB125CBT IN type.

Country Codes

Code	Country
ACB125CBF	
IN	Indonesia
PH	Philippines
ACB125CBT	
IN	Indonesia

*The specifications may vary with each locale.

A Few Words About Safety

Your safety, and the safety of others, is very important. Operating this scooter safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on safety labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all hazards associated with operating or maintaining a scooter. You must use your own good judgement.

You will find important safety information in a variety of forms, including:

- Safety labels on the scooter.
- Safety Messages preceded by a safety alert symbol  and one of three signal words: DANGER, WARNING, or CAUTION.

These signal words mean:

DANGER

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

WARNING

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

CAUTION

You **CAN** be **HURT** if you don't follow instructions.

Other important information is provided under the following titles:

NOTICE Information to help you avoid damage to your scooter, other property, or the environment.

Contents

Scooter Safety P. 2

Operation Guide P. 12

Maintenance P. 55

Troubleshooting P. 92

Information P. 105

Specifications P. 118

Index P. 121

Scooter Safety

This section contains important information for safe riding of your scooter.
Please read this section carefully.

Safety Guidelines	P. 3
Safety Precautions	P. 6
Riding Precautions.....	P. 7
Accessories & Modifications.....	P. 10
Loading	P. 11

Safety Guidelines

Safety Guidelines

Follow these guidelines to enhance your safety:

- Perform all routine and regular inspections specified in this manual.
- Stop the engine and keep sparks and flame away before filling the fuel tank.
- Do not run the engine in enclosed or partly enclosed areas. Carbon monoxide in exhaust gases is toxic and can kill you.

Always Wear a Helmet

It's a proven fact: helmets and protective apparel significantly reduce the number and severity of head and other injuries. So always wear an approved motorcycle helmet and protective apparel.  P. 6

Before Riding

Make sure that you are physically fit, mentally focused and free of alcohol and drugs. Check

that you and your passenger are both wearing an approved motorcycle helmet and protective apparel. Instruct your passenger on holding onto the grab rail or your waist, leaning with you in turns, and keeping their feet on the footpegs, even when the scooter is stopped.

Take Time to Learn & Practice

Even if you have ridden other scooters, practice riding in a safe area to become familiar with how this scooter works and handles, and to become accustomed to the scooter's size and weight.

Ride Defensively

Always pay attention to other vehicles around you, and do not assume that other drivers see you. Be prepared to stop quickly or perform an evasive maneuver.

Safety Guidelines

Make Yourself Easy to See

Make yourself more visible, especially at night, by wearing bright reflective clothing, positioning yourself so other drivers can see you, signaling before turning or changing lanes, and using your horn when necessary.

Ride within Your Limits

Never ride beyond your personal abilities or faster than conditions warrant. Fatigue and inattention can impair your ability to use good judgement and ride safely.

Don't Drink and Ride

Alcohol and riding don't mix. Even one alcoholic drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. Don't drink and ride, and don't let your friends drink and ride either.

Keep Your Honda in Safe Condition

It's important to keep your scooter properly maintained and in safe riding condition. Inspect your scooter before every ride and perform all recommended maintenance. Never exceed load limits (➤ P. 11), and do not modify your scooter or install accessories that would make your scooter unsafe (➤ P. 10).

If You are Involved in a Crash

Personal safety is your first priority. If you or anyone else has been injured, take time to assess the severity of the injuries and whether it is safe to continue riding. Call for emergency assistance if needed. Also follow applicable laws and regulations if another person or vehicle is involved in the crash.

If you decide to continue riding, first turn the ignition switch to the **O** (Off) position, and evaluate the condition of your scooter.

Inspect for fluid leaks, check the tightness of critical nuts and bolts, and check the handlebar, control levers, brakes, and wheels. Ride slowly and cautiously. Your scooter may have suffered damage that is not immediately apparent. Have your scooter thoroughly checked at a qualified service facility as soon as possible.

Carbon Monoxide Hazard

Exhaust contains poisonous carbon monoxide, a colourless, odorless gas. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

If you run the engine in confined or even partly enclosed area, the air you breathe could contain a dangerous amount of carbon monoxide. Never run your scooter inside a garage or other enclosure.

WARNING

Running the engine of your scooter while in an enclosed or even partially enclosed area can cause a rapid build-up of toxic carbon monoxide gas.

Breathing this colourless, odorless gas can quickly cause unconsciousness and lead to death.

Only run your scooter's engine when it is located in a well ventilated area outdoors.

Safety Precautions

Safety Precautions

- Ride cautiously and keep your hands on the handlebar and feet on the floor.
- Keep passenger's hands onto the grab rail or your waist, passenger's feet on the footpegs while riding.
- Always consider the safety of your passenger, as well as other drivers and riders.

Protective Apparel

Make sure that you and any passenger are wearing an approved motorcycle helmet, eye protection, and high-visibility protective clothing. Ride defensively in response to weather and road conditions.

■ Helmet

Safety-standard certified, high-visibility, correct size for your head

- Must fit comfortably but securely, with the chin strap fastened.

- Face shield with unobstructed field of vision or other approved eye protection

WARNING

Not wearing a helmet increases the chance of serious injury or death in a crash.

Make sure that you and any passenger always wear an approved helmet and protective apparel.

■ Gloves

Full-finger leather gloves with high abrasion resistance

■ Boots or Riding Shoes

Sturdy boots with non-slip soles and ankle protection

■ Jacket and Trousers

Protective, highly visible, long-sleeved jacket and durable trousers for riding (or a protective suit)

Riding Precautions

Running-in Period

During the first 500 km (300 miles) of running, follow these guidelines to ensure your scooter's future reliability and performance.

- Avoid full-throttle starts and rapid acceleration.
- Avoid hard braking.
- Ride conservatively.

Brakes

Observe the following guidelines:

- Avoid excessively hard braking.
 - ▶ Sudden braking can reduce the scooter's stability.
 - ▶ Where possible, reduce speed before turning; otherwise you risk sliding out.
- Exercise caution on low traction surfaces.
 - ▶ The tyres slip more easily on such surfaces, and braking distances are longer.

- Avoid continuous braking.
 - ▶ Repeated braking, such as when descending long, steep slopes can seriously overheat the brakes, reducing their effectiveness.
- For full brake effectiveness, operate both the front and rear brakes together.

Combi Brake

Your scooter is equipped with a brake system that distributes the braking force between the front and rear brakes.

The distribution of the braking force applied to the front and rear brakes when operating the front brake lever only and when operating the rear brake lever only is different.

For full braking effectiveness, operate both the front and rear brakes together.

Riding Precautions

Wet or Rainy Conditions

Road surfaces are slippery when wet, and wet brakes further reduce braking efficiency. Exercise extra caution when braking in wet conditions.

If the brakes get wet, apply the brakes while riding at low speed to help them dry.

Parking

- Park on a firm, level surface.
- If you must park on a slight incline or loose surface, park so that the scooter cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.

- To reduce the likelihood of theft, always lock the handlebar and remove the key and close the shutter when leaving the scooter unattended.

Use of an anti-theft device is also recommended.

ACB125CBT

Also set the anti-theft alarm system.

Parking with the Side Stand or Centre Stand

1. Stop the engine.

2. Using the side stand

Push the side stand down.


Slowly lean the scooter to the left until its weight rests on the side stand.

Using the centre stand

To lower the centre stand, stand on the left side of the scooter.

Hold the left handle grip and the grab rail.

Press down on the tip of the centre stand with your right foot and, simultaneously, pull up and back.



3. Turn the handlebar fully to the left.
 ► Turn the handlebar to the right reduces stability and may cause the scooter to fall.
4. Turn the ignition switch to the  (Lock) position (➡ P. 27), remove the key and close the shutter (➡ P. 29).
5. **ACB125CBT**
 Set the anti-theft alarm system. ➡ P. 31

Refuelling and Fuel Guidelines

Follow these guidelines to protect the engine, fuel system and catalytic converter:

- Use only unleaded petrol.
- Use recommended octane number. Using lower octane petrol will result in decreased engine performance.
- Do not use fuels containing a high concentration of alcohol. ➡ P. 116
- Do not use stale or contaminated petrol or an oil/petrol mixture.
- Avoid getting dirt, or water in the fuel tank.

Accessories & Modifications

We strongly advise that you do not add any accessories that were not specifically designed for your scooter by Honda or make modifications to your scooter from its original design. Doing so can make it unsafe. Modifying your scooter may also void your warranty and make your scooter illegal to operate on public roads and highways. Before deciding to install accessories on your scooter be certain the modification is safe and legal.

WARNING

Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Do not pull a trailer with, or attach a sidecar to, your scooter. Your scooter was not designed for these attachments, and their use can seriously impair your scooter's handling.

Loading

- Carrying extra weight affects your scooter's handling, braking and stability. Always ride at a safe speed for the load you are carrying.
- Avoid carrying an excessive load and keep within specified load limits.

Maximum weight capacity / Maximum luggage weight ➤ P. 118

- Tie all luggage securely, evenly balanced and close to the centre of the scooter.
- Do not place objects near the lights or the muffler.

WARNING


Overloading or improper loading can cause a crash and you can be seriously hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Basic Operation Flow

Pre-ride Inspection ➡ P. 60

Carefully inspect your scooter to make sure that it is safe to ride.



How to use basic features.

- Instruments ➡ P. 16
- Indicators ➡ P. 24
- Switches ➡ P. 26
- Steering Lock ➡ P. 28
- Anti-theft Alarm System (ACB125CBT) ➡ P. 30
- Answer Back System (ACB125CBT) ➡ P. 34
- Rear Brake Lock ➡ P. 39
- Shutter ➡ P. 29
- Idling Stop System (ACB125CBT) ➡ P. 40

Acceleration ➡ P. 47

Apply throttle gradually.
Obey the speed limit.



Starting the Engine ➡ P. 43

Start and warm the engine.
Avoid revving the engine.



Starting the Scooter ➡ P. 47

Before pulling away, indicate your direction with the turn signal switch, and check for oncoming traffic.



Braking ➡ P. 48**STOP!**

Close the throttle and apply the front and rear brakes together.

► The brakelight will indicate that you have applied the brakes.

Stopping

If pulling off the road, signal early enough to show traffic that you are pulling over, and pull over smoothly.

**Turning Corners**


Do your braking before entering corners.




Gradually reapply throttle when exiting turn.


Parking ➡ P. 8

Park on a firm level surface. Use the stand, lock the steering.


**Refuelling** ➡ P. 49

Parts Location





Instruments



Speedometer

This shows your speed in kilometer per hour (km/h).

Display Check


When the ignition switch is turned to the **I** (On) position, the display will temporarily show all the modes and digital segments so you can make sure the liquid crystal display is functioning properly.

If any part of these displays do not come on when it should, have your dealer check for problems.

Fuel gauge

Remaining fuel when only 1st (E) segment starts flashing approximately: 1.2 litres (0.32 US gal, 0.26 Imp gal)

If the fuel gauge indicator flashes in a repeat pattern or turns off: ➡ P.96

**Clock (12-hour display)**

To set the clock: ➡ P.21

Current fuel mileage

Current instant fuel mileage. If your speed is less than 3 km/h, "0" is displayed. When "0" is displayed at speeds above 3 km/h, go to your dealer for service.


Odometer [TOTAL]/Tripmeter [TRIP A/B]/Average fuel mileage meter [AVG]/Battery voltage meter [V]

➡ P.18

Instruments *(Continued)*

Odometer [TOTAL]/Tripmeter [TRIP A/B]/Average fuel mileage meter [AVG]/ Battery voltage meter [V]

SELECT button selects the odometer, tripmeter A, tripmeter B, average mileage and battery voltage.




- Odometer:
Total distance ridden.
- Tripmeter:
Distance ridden since tripmeter was reset.
► To reset tripmeter, press and hold **SET** button the mode switch with tripmeter displayed.
When to reset tripmeter A, the average fuel mileage is also reset.
- Average fuel mileage:
The average fuel mileage will be based on tripmeter A.
Average fuel mileage since tripmeter A was reset.
When " -.- " is displayed except after the average fuel mileage has been reset, go to your dealer for service.
- Battery voltage:
Current battery voltage.

OIL CHANGE indicator

The indicator is turned on whenever the running distance reaches the programmed oil change interval.

- ▶ When the running distance reaches about 1,000 km:
Reset the indicator for the 1st time.
- ▶ When the running distance reaches about every 6,000 km after the 1st time resetting:
Reset the indicator whenever it is turned on.

After changing the engine oil  P.76, be sure to reset the indicator.



To reset the indicator, press and hold the **SET** button while turning the ignition switch to the **I** (On) position, and keep holding the **SET** button for more than 3 seconds.

- ▶ The indicator does not go off until it is reset.
- ▶ If the oil is changed before the oil change indicator comes on, be sure to reset the oil change indicator after changing the oil. When resetting the indicator during no indication, the indicator will appear for 2 seconds, then disappear.

Instruments *(Continued)*

Display Setting


Following items can be changed sequentially.

- Clock setting
- OIL CHANGE indicator setting

➡ Press and hold **SELECT** button and **SET** button

➡ Press **SET** button

➡ Press **SELECT** button



The following moves the ordinary display at display setting.

- The button is not pressed for about 30 seconds
- Turn the ignition switch to the **○** (Off) position and then to the **||** (On) position

1 Clock setting:


- ① Turn the ignition switch to the I (On) position.
- ② Press and hold **SELECT** button and **SET** button, the all clock digits start flashing.
- ③ Press **SET** button, the hour digits start flashing.
- ④ Press **SELECT** button until the desired hour is displayed.
▶ Press and hold to advance the hour fast.



- ⑤ Press **SET** button. The minute digits start flashing.



- ⑥ Press **SELECT** button until the desired minute is displayed.
▶ Press and hold to advance the minute fast.



- ⑦ Press **SET** button. The clock is set, and then the display moves to the interval value of OIL CHANGE indicator.

Instruments (Continued)

2 OIL CHANGE indicator setting:

The distance until the OIL CHANGE indicator comes on is displayed.

You can adjust the interval value of OIL CHANGE indicator.

- 1 Press **SET** button. The OIL CHANGE indicator start flashing.



- 2 Press **SELECT** button until the desired value is displayed




- 3 Press **SET** button. The OIL CHANGE indicator is set.


The established setting can also be set by turning the ignition switch to the **OFF** position.

The control is automatically switched from the setting mode to the ordinary display if the switch is not pressed for about 30 seconds. In this case, undecided settings will not be maintained.

Indicators

If one of these indicators does not come on when it should, have your dealer check for problems.



**Idling Stop indicator****ACB125CBT**

Comes on briefly when the Idling Stop switch in the IDLING STOP with the ignition switch turned to the **I** (On) position.

Flashes when the Idling Stop system is activated.


Alarm indicator**ACB125CBT**

Anti-theft Alarm system: ➡ P. 30

**Battery Charging Condition indicator**

When the Battery Charging Condition indicator on: ➡ P. 95


Switches



Ignition switch

Switches the electrical system on/off, locks the steering, and operates the seat opener switch.

- Key can be removed when in the ○ (Off) or  (Lock) position.



SET button/UNSET button/ ANSWER BACK button

ACB125CBT

These buttons are used to operate the anti-theft alarm system and answer back system.

Anti-theft Alarm System:  **P. 30**

Answer Back System:  **P. 34**

I (On)
Turns electrical system on for starting/riding.

SEAT
Operates the seat opener switch.

○ (Off)
Turns engine off.

 (Lock)
Locks steering.




Switches *(Continued)*

Steering Lock

Lock the steering when parking to help prevent theft.

A U-shaped wheel lock or similar device is also recommended.



Locking


- 1 Turn the handlebar all the way to the left or right.
- 2 Push the key down, and turn the ignition switch to the  (Lock) position.
 - Jiggle the handlebar if the lock is difficult to engage.
- 3 Remove the key.

Unlocking

Insert the key, push it in, and turn the ignition switch to the  (Off) position.

Shutter

The ignition switch for this scooter is equipped with an automatic shutter. After parking the scooter, close the shutter for theft prevention.



The shutter will automatically close when you remove the ignition key at the **(Lock)** position.

Also you can close the shutter manually.

Close

- 1 Remove the ignition key from the ignition switch.
- 2 Align the projection of the shutter key with the slot of the shutter, and turn the shutter key counterclockwise.
- 3 Remove the key.

Open

Align the projection of the shutter key with the slot of the shutter, and turn the shutter key clockwise.


Anti-theft Alarm System

ACB125CBT

The anti-theft alarm system is a device to reduce the likelihood of theft. When the sensor detects vibration or movement with the ignition switch in the **○** (Off) or **🔒** (Lock) position and the system is set, the alarm is activated.

The alarm sounds and the turn signals blink for about 10 seconds when the anti-theft alarm system detects vibration caused by contact or movement.

The alarm sounds and the turn signals blink for about 60 seconds when the anti-theft alarm system detects a substantial change in the scooter posture. After the alarm sounds for 60 seconds, the anti-theft alarm system will be reset in that posture.



If the ignition switch is left in the **○** (Off) position for more than 10 days, the anti-theft alarm system will no longer operate. During the system is activating, when the scooter receives a signal by pressing the SET/UNSET button, the system activation will be extended for 10 days. To reset the system, turn the ignition switch to the **I** (On) position once.

The anti-theft alarm system uses low-intensity radio waves. It may affect medical equipment such as a cardiac pacemaker.

NOTICE

When the battery in the scooter is weak, the anti-theft alarm system may not function.

Setting the Anti-theft Alarm System

- 1 Turn the ignition switch to the **○** (Off) position or the **🔒** (Lock) position.
- 2 Press the SET button. Within a second, the turn signal light blinks and the buzzer sounds for 1 time. After 2 seconds, the buzzer

sounds 1 time. The anti-theft alarm system is activated.


The buzzer sound can be cancelled using temporary silence mode.

Temporary Silence Mode ➡ P. 38

The alarm indicator flashes while the alarm system is activated.

The anti-theft alarm system is cancelled when ignition switch is turned to the **I** (On) position.

SET button



Alarm indicator



Cancelling the Anti-theft Alarm System ➡ P. 32

Adjusting the Sensitivity of Anti-theft Alarm System ➡ P. 32

If the Anti-theft Alarm System Does Not Operate Properly ➡ P. 33

Anti-theft Alarm System *(Continued)*


■ Cancelling the Anti-theft Alarm System

Press the UNSET button or turn the ignition switch to the **I (On)** position.


When UNSET button is pressed, the turn signal light blinks, the alarm indicator blinks, and the alarm sounds for 2 times. The buzzer sound can be cancelled using temporary silence mode.

■ Temporary Silence Mode P. 38

UNSET button



I (On)




■ Stopping the Anti-theft Alarm Activation

To stop the anti-theft alarm activation, do one of the following:


- Press the UNSET button.
- Turn the ignition switch to the **I (On)** position.

After stopping the anti-theft alarm activation, the anti-theft alarm system will be cancelled.

UNSET button



I (On)




■ Adjusting the Sensitivity of Anti-theft Alarm System

You can select 3 sensitivity levels of anti-theft alarm system.

- 1 Turn the ignition switch to the **O (Off)** position.
- 2 Repeat this step 3 times as follows:
Turn the ignition switch from the **O (Off)** position to the **I (On)** position and press SET button on remote transmitter 2 times. Then turn the ignition switch from the **O (Off)** position to the **I (On)** position within 5 seconds.

- You need to operate this process from the **○ (Off)** position to the **■ (On)** position within 5 seconds.



- 3 Turn and keep the ignition switch to the **■ (On)** position. Press the SET button to select among 3 sensitivity levels of anti-theft alarm system.
 3 times of alarm sound: high sensitivity
 2 times of alarm sound: middle sensitivity
 1 time of alarm sound: low sensitivity
 The alarm indicator lights while setting.
- 4 Turn the ignition switch to the **○ (Off)** position to finish setting the sensitivity level.

To complete your setting, you need to go through step 3 within 60 seconds.

Make sure that LED on the remote transmitter is green before setting the sensitivity level.

Because if it is red, you cannot set the sensitivity level.

■ If the Anti-theft Alarm System Does Not Operate Properly

If any of the following situations arise, battery (► P. 61) in the scooter is discharged or there is a system problem. Remove the battery and see your dealer.


The alarm does not sounds.
 The alarm sounds but fades out.
 The alarm system does not stop.

Answer Back System


ACB125CBT

The answer back system is a device to find the position of your scooter. When you press the ANSWER BACK button on the remote transmitter with the ignition switch in the ○ (Off) or 🔒 (Lock) position, your scooter informs you the position by blinking the turn signal light and sounding the buzzer.

The answer back system uses low-intensity radio waves. It may affect medical equipment such as a cardiac pacemaker.



ANSWER
BACK button



Operation

Press the ANSWER BACK button on the remote transmitter.

- ▶ Answer back system will not function when the ignition switch is in the **I** (On) position.

If the ignition switch is left in the **O** (Off) position for more than 10 days, the answer back system will no longer operate. During the system is activating, when the scooter receives a signal by pressing the SET/UNSET button, the system activation will be extended for 10 days. To reset the system, turn the ignition switch to the **I** (On) position once.

NOTICE

When the battery in the scooter is weak, the anti-theft alarm system may not function.

Adjusting the Answer Back Buzzer Sound Volume Level ➡P.36

Changing the Answer Back Buzzer Sound Pattern ➡P.37

Temporary Silence Mode ➡P.38

Replacing the Remote Transmitter Battery ➡P.90

Answer Back System *(Continued)*


Adjusting the Answer Back Buzzer Sound Volume Level

You can select 3 buzzer sound volume levels or mute.

- 1 Turn the ignition switch to the **○** (Off) position.
- 2 Repeat this step 3 times as follows:
Turn the ignition switch from the **○** (Off) position to the **I** (On) position and press ANSWER BACK button on remote transmitter 2 times.

Then turn the ignition switch from the **I** (On) position to the **○** (Off) position within 5 seconds.

- You need to operate this process from the **○** (Off) position to the **I** (On) position within 5 seconds.



- 3 Turn and keep the ignition switch to the **I** (On) position. Press the ANSWER BACK button to select among 3 levels of sound volume or mute.
- 4 Turn the ignition switch to the **○** (Off) position to finish setting the buzzer sound volume level.


To complete your setting, you need to go through step 3 within 60 seconds.

Make sure that LED on the remote transmitter is green before setting the buzzer sound volume level. Because if it is red, you cannot set the buzzer sound volume level.

Changing the Answer Back Buzzer Sound Pattern

You can select 3 buzzer sound patterns.

- 1 Turn the ignition switch to the **○ (Off)** position.
- 2 Repeat this step 3 times as follows:
Turn the ignition switch from the **○ (Off)** position to the **I (On)** position and press ANSWER BACK button on remote transmitter 3 times.
Then turn the ignition switch from the **I (On)** position to the **○ (Off)** position within 5 seconds.
▶ You need to operate this process from the **○ (Off)** position to the **I (On)** position within 5 seconds.



- 3 Turn and keep the ignition switch to the **I (On)** position. Press the ANSWER BACK button to select among 3 buzzer sound patterns.
- 4 Turn the ignition switch to the **○ (Off)** position to finish setting the buzzer sound patterns.

To complete your setting, you need to go through step 3 within 60 seconds.

Make sure that LED on the remote transmitter is green before setting the buzzer sound patterns. Because if it is red, you cannot set the buzzer sound patterns.

Answer Back System *(Continued)*

Temporary Silence Mode

Temporary silence mode is the immediate way to turn off the answer back system buzzer sound.

Enable:

Press and hold ANSWER BACK button about 2 seconds, the LED on remote transmitter is changed to be red.

Disable:

Re-press and hold ANSWER BACK button about 2 seconds, the LED on remote transmitter is changed to be green.


Rear Brake Lock

Be sure the rear brake lock is applied while starting and warming up the engine.

Locking

Squeeze the rear brake lever and set the rear brake lock lever.


- The rear brake lock will not function if the rear brake is not adjusted properly. ➡ P. 82



Unlocking

Squeeze the rear brake lever.

- Before riding, make sure that the rear brake lock is fully released so there is no drag on the rear wheel.



Idling Stop System

ACB125CBT

Idling Stop system is designed to help reduce the fuel consumption and noise, by idling stop while making a stop such as waiting at an intersection.

Switching the Idling Stop System On or Off

Switches the Idling Stop system on or off using the Idling Stop switch.

- **ON: IDLING STOP**
 - ▶ Idling Stop indicator comes on when the Idling Stop system becomes ready to stop the engine while riding. Idling Stop indicator flashes when the engine is stopped by the Idling Stop system.
- **OFF: IDLING**
 - ▶ Idling Stop indicator does not come on when the Idling Stop system is off.


Activation of the Idling Stop System

The Idling Stop system becomes ready to stop the engine and Idling Stop indicator comes on when the following requirements are satisfied with the Idling Stop switch in the IDLING STOP position:

- Started the engine by the start button.
- Warmed up the engine enough
- Ridden the scooter at speed over 10 km/h (6 mph).

Idling Stop Indicator Does Not Come


On: ➡ P. 97



Stopping the engine by the Idling Stop System

The engine stops and Idling Stop indicator changes to flash after you close the throttle completely and stop the scooter while the Idling Stop indicator is on.

- ▶ While the engine is stopped by the Idling Stop system, if you press the Idling Stop switch to IDLING, the Idling Stop system will be cancelled. The engine will not restart even when you open the throttle.



Safety Precaution for the Idling Stop System

Do not go away from the scooter while the Idling Stop indicator is flashing. When you go away from the scooter, always turn the ignition switch to the **○** (Off) position.

- ▶ The engine may start unexpectedly if the throttle is opened.

Engine is Not Stopped by the Idling Stop System While the Idling Stop Indicator is On: ➡ P. 98

NOTICE

Stopping by the Idling Stop system for a long time may cause battery discharge.

Idling Stop System *(Continued)*

Restarting the Engine

Check that the Idling Stop indicator is flashing, and then open the throttle.

- ▶ If it is not flashing, you can't restart the engine with the Idling Stop system, even if you open the throttle.
- ▶ While the engine is stopped by the Idling Stop system, if you operate the side stand, the flashing Idling Stop indicator turns off or stops flashing and stays on, then the engine will not restart even when you open the throttle.

Engine Does Not Start Even If the Throttle is Opened: ➡ P.99

NOTICE

Headlight stays on after the engine is stopped by the Idling Stop system. The battery may discharge and you may not be able to restart engine.

When the battery is weak, switch the Idling Stop switch to IDLING and do not use the Idling Stop system. See your dealer to check the battery.

See your dealer for checking the battery as specified in the maintenance schedule.

Maintenance Schedule: ➡ P.57

Starting the Engine

Start your engine using the following procedure, regardless of whether the engine is cold or warm.

This scooter is equipped with a side stand ignition cut-off system.

- If the side stand is down, the engine cannot be started.
- If you lower the side stand with the engine running, it will automatically shut off.

NOTICE

- If the engine does not start within 5 seconds, turn the ignition to the **○** (Off) position and wait 10 seconds before trying to start the engine again to recover battery voltage.
- Extended fast idling and revving the engine can damage the engine, and the exhaust system.
- If the scooter is over-turned, you must first turn the ignition switch to the **○** (Off) position and then inspect the scooter carefully.


Consult your dealer for advice if you plan to ride your scooter at an altitude above 2,500 m (8,000 feet).

NOTICE


If the scooter is transported to a place 2,000 m (6,500 feet) higher or lower than the start point, you may not be able to achieve sufficient engine performance at the new altitude. Consult your dealer before transporting your scooter.

Starting the Engine *(Continued)*


- 1 Place the scooter on its centre stand.
- 2 Turn the ignition switch to the I (On) position. Confirm the following:
 - The PGM-FI malfunction indicator lamp (MIL) is OFF.
 - The high coolant temperature indicator is OFF.



- 3 Lock the rear wheel by squeezing the rear brake lever and setting the brake lock lever.
 - The starter motor will only work when the brake lever is squeezed and the side stand is up.



- 4 With the throttle completely closed, press the start button. Release the start button as soon as the engine starts.




Starting the Engine *(Continued)*

If you cannot start the engine:

Open the throttle slightly (about 3 mm, without freeplay).

About 3 mm, without freeplay



If the engine does not start:

- ① Open the throttle fully and press the start button for 5 seconds.
- ② Follow the normal starting procedure.
- ③ If the engine starts with unstable idle, open the throttle slightly.
- ④ If the engine does not start, wait for 10 seconds, then follow steps ① - ③ again.

If Engine Will Not Start ➡ P.93

Riding


Starting the Scooter

- 1 Push the scooter forward off the centre stand.
 - ▶ Lock the rear brake lock.
 - ▶ Keep throttle closed.

Make sure the side stand and centre stand are up.

- 2 Get on the scooter.
 - ▶ Mount the scooter from the left side, keeping at least one foot on the ground.
- 3 Release the rear brake lock.
 - ▶ To prevent unexpected movement, squeeze both brake levers.

- 4 Acceleration and deceleration
To accelerate: Open the throttle slowly.
To decelerate: Close the throttle.




Riding *(Continued)*

Braking

Close the throttle and apply the front and rear brake levers together.

Do not apply the brake lock while riding. It may cause the wheel to lock, reducing control of the scooter.



NOTICE

To prevent clutch damage, do not use the throttle to keep the scooter stopped at up hill.

Refuelling

Fuel type: Unleaded petrol only


Fuel octane number: Your scooter is designed to use Research Octane Number (RON) 88 or higher.

Tank capacity: 5.5 litres (1.45 US gal, 1.21 Imp gal)

Refuelling and Fuel Guidelines ➡ P.9

Opening the Fuel Fill Cap

- 1 Open the seat. ➡ P.51
- 2 Turn the fuel fill cap counterclockwise until it stops and remove the cap.



Do not fill with fuel above the lower edge of the filler neck.

Refuelling *(Continued)*

Closing the Fuel Fill Cap


- ① Install and tighten the fuel fill cap firmly by turning it clockwise.
 - ▶ Make sure that the arrow marks on the cap and fuel tank are aligned.
- ② Close the seat.

WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Storage Equipment



Seat Open

- 1 Turn the handlebar pointed straight ahead.
- 2 Insert the ignition key and turn it to the position of SEAT.
- 3 Push the SEAT side of the seat opener switch.
- 4 Open the seat.

Seat Close


Close and push down on the rear of the seat until locks. Make sure that the seat is locked securely to pull it up lightly. Take care not to lock your key in the compartment under the seat.

Storage Equipment *(Continued)*

Helmet Holder

The helmet holders are located under the seat.

- Use the helmet holders only when parked.



⚠ WARNING

Riding with a helmet attached to the holder can interfere with your ability to safely operate the scooter and could lead to a crash in which you can be seriously hurt or killed.


Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.

Luggage Box

Never exceed the maximum weight limit.

Maximum Weight: 10 kg (22 lb)

- ▶ Do not store any items that are flammable or susceptible to heat damage.
- ▶ Do not store valuables or fragile articles.



Tool

The tools are on the reverse side of the seat.

Document Bag


The document bag is in the document compartment on the reverse side of the seat.

Storage Equipment *(Continued)*

Hook


The hook is provided below the handlebar.

- Do not attach large luggage to the hook that would hang out from the scooter and/or interfere with the movement of your feet.



Glove Box

The glove box is provided below the handlebar.



The maximum allowable load on the hook and the glove box shall be no more than **1.5 kg (3.3 lb)**.

Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

Importance of Maintenance	P. 56	Coolant	P. 79
Maintenance Schedule	P. 57	Brakes	P. 81
Maintenance Fundamentals	P. 60	Side Stand	P. 86
Tool	P. 70	Throttle	P. 87
Removing & Installing Body Components ...	P. 71	Crankcase Breather	P. 88
Battery.....	P. 71	Other Adjustments	P. 89
Spark Plug	P. 73	Adjusting the Headlight Aim	P. 89
Engine Oil	P. 75	Other Replacement	P. 90
		Replacing the Remote Transmitter Battery	P. 90

Importance of Maintenance

Importance of Maintenance

Keeping your scooter well-maintained is absolutely essential to your safety and to protect your investment, obtain maximum performance, avoid breakdowns, and reduce air pollution. Maintenance is the owner's responsibility. Be sure to inspect your scooter before each ride, and perform the periodic checks specified in the Maintenance Schedule. ➤ P. 57

WARNING

Improperly maintaining your scooter or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

Maintenance Safety

Always read the maintenance instructions before you begin each task, and make sure that you have the tools, parts, and skills required. We cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

Follow these guidelines when performing maintenance.

- Stop the engine and remove the key.
- Place your scooter on a firm, level surface using the side stand, centre stand or a maintenance stand to provide support.
- Allow the engine, muffler, brakes, and other high-temperature parts to cool before servicing as you can get burned.
- Run the engine only when instructed, and do so in a well-ventilated area.

Maintenance Schedule

The maintenance schedule specifies the maintenance requirements necessary to ensure safe, dependable performance, and proper emission control.

Maintenance work should be performed in accordance with Honda's standards and specifications by properly trained and equipped technicians. Your dealer meets all of these requirements. Keep an accurate record of maintenance to help ensure that your scooter is properly maintained. Make sure that whomever performs the maintenance completes this record.

All scheduled maintenance is considered a normal owner operating cost and will be charged to you by your dealer. Retain all receipts. If you sell the scooter, these receipts should be transferred with the scooter to the new owner.

Honda recommends that your dealer should road test your scooter after each periodic maintenance is carried out.

Maintenance Schedule

Items		Pre-ride Check P. 60	Frequency *1								Annual Check	Regular Replace	Refer to page
			× 1,000 km	1	6	12	18	24	30	36			
			× 1,000 mi	0.6	4	8	12	16	20	24			
Fuel Line					I	I	I	I	I	I	I		–
Fuel Level		I											–
Throttle Operation		I			I	I	I	I	I	I	I		87
Air Cleaner *2							R			R			–
Crankcase Breather *3					C	C	C	C	C	C			88
Spark Plug					I	R	I	R	I	R			73
Valve Clearance					I	I	I	I	I	I			–
Engine Oil		I		R	R	R	R	R	R	R	R		75
Engine Oil Strainer Screen						C		C		C			–
Engine Idle Speed				I	I	I	I	I	I	I	I		–
Radiator Coolant *4		I				I		I		I	I	3 Years	79
Cooling System						I		I		I	I		–
Drive Belt						I		R		I			–

Maintenance Level

-  : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
-  : Technical. In the interest of safety, have your scooter serviced by your dealer.

Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
- R** : Replace
- C** : Clean

Maintenance Schedule

Items		Pre-ride Check  P. 60	Frequency ^{*1}								Annual Check	Regular Replace	Refer to page
			× 1,000 km	1	6	12	18	24	30	36			
			× 1,000 mi	0.6	4	8	12	16	20	24			
Final Drive Oil ^{*4}												2 Years	–
Battery (ACB125CBT)													61
Brake Fluid ^{*4}												2 Years	81
Brake Shoes/Pads Wear													82, 85
Brake System													81
Brake Lock Operation													–
Headlight Aim													89
Lights/Horn													–
Clutch Shoes Wear													–
Side Stand													86
Suspension													–
Nuts, Bolts, Fasteners													–
Wheels/Tyres													66
Steering Head Bearings													–

Notes:

*1 : At higher odometer reading, repeat at the frequency interval established here.

*2 : Service more frequently when riding in unusually wet or dusty areas.

*3 : Service more frequently when riding in rain or at full throttle.

*4 : Replacement requires mechanical skill.

Maintenance Fundamentals

Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A pre-ride inspection is a must, not only for safety, but because having a breakdown, or even a flat tyre, can be a major inconvenience.

Check the following items before you get on your scooter:

- Fuel level-Fill fuel tank when necessary. ➡ P. 49
- Throttle-Check for smooth opening and full closing in all steering positions. ➡ P. 87
- Engine oil level-Add engine oil if necessary. Check for leaks. ➡ P. 75
- Coolant level-Add coolant if required. Check for leaks. ➡ P. 79

- Brakes-Check operation;
Front: check brake fluid level and pads wear. ➡ P. 81, 82
Rear: check shoes wear and freeplay, adjust if necessary. ➡ P. 82, 85
- Lights and horn-Check that lights, indicators and horn function properly.
- Side stand ignition cut-off system-Check for proper function. ➡ P. 43, 86
- Wheels and tyres-Check condition, air pressure and adjust if necessary. ➡ P. 66

Replacing Parts

Always use Honda Genuine Parts or their equivalents to ensure reliability and safety.

WARNING

Installing non-Honda parts may make your scooter unsafe and cause a crash in which you can be seriously hurt or killed.

Always use Honda Genuine Parts or equivalents that have been designed and approved for your scooter.

Battery

Your scooter has a maintenance-free type battery. You do not have to check the battery electrolyte level or add distilled water. Clean the battery terminals if they become dirty or corroded.

Do not remove the battery cap seals. There is no need to remove the cap when charging.

NOTICE

Your battery is a maintenance-free type and can be permanently damaged if the cap strip is removed.



This symbol on the battery means that this product must not be treated as household waste.

NOTICE

An improperly disposed of battery can be harmful to the environment and human health.

Always confirm local regulations for proper battery disposal instruction.

Maintenance Fundamentals

What to do in an emergency

If any of the following occur, immediately see your doctor.

- Electrolyte splashes into your eyes:
 - ▶ Wash your eyes repeatedly with cool water for at least 15 minutes. Using water under pressure can damage your eyes.
- Electrolyte splashes onto your skin:
 - ▶ Remove affected clothing and wash your skin thoroughly using water.
- Electrolyte splashes into your mouth:
 - ▶ Rinse mouth thoroughly with water, and do not swallow.

WARNING

The battery gives off explosive hydrogen gas during normal operation.


A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

Wear protective clothing and a face shield, or have a skilled mechanic do the battery servicing.

Cleaning the Battery Terminals

1. Remove the battery. ➤ P. 71
2. If the terminals are starting to corrode and are coated with a white substance, wash with warm water and wipe clean.

3. If the terminals are heavily corroded, clean and polish the terminals with a wire brush or sandpaper. Wear safety glasses.



4. After cleaning, reinstall the battery.

The battery has a limited life span. Consult your dealer about when you should replace the battery. Always replace the battery with another maintenance-free battery of the same type.

NOTICE


Installing non-Honda electrical accessories can overload the electrical system, discharging the battery and possibly damaging the system.

Fuses

Fuses protect the electrical circuits on your scooter. If something electrical on your scooter stops working, check for and replace any blown fuses. ➤ P. 103

Inspecting and Replacing Fuses

Turn the ignition switch to the **○** (Off) position to remove and inspect fuses. If a fuse is blown, replace with a fuse of the same rating. For fuse ratings, see "Specifications." ➤ P. 120

**NOTICE**

Replacing a fuse with one that has a higher rating greatly increases the chance of damage to the electrical system.

Maintenance Fundamentals

If a fuse fails repeatedly, you likely have an electrical fault. Have your scooter inspected by your dealer.

Engine Oil

Engine oil consumption varies and oil quality deteriorates according to riding conditions and time elapsed.

Check the engine oil level regularly, and add the recommended engine oil if necessary. Dirty oil or old oil should be changed as soon as possible.


Selecting the Engine Oil

For recommended engine oil, see "Specifications." ▢ P. 119


If you use non-Honda engine oil, check the label to make sure that the oil satisfies all of the following standards:

- JASO T 903 standard*1: MB
- SAE standard*2: 10W-30
- API classification*3: SG or higher

- *1. The JASO T 903 standard is an index for engine oils for 4-stroke motorcycle engines. There are two classes: MA and MB. For example, the following label shows the MB classification.



- *2. The SAE standard grades oils by their viscosity.
- *3. The API classification specifies the quality and performance rating of engine oils. Use SG or higher oils, excluding oils marked as "Energy Conserving" or "Resource Conserving" on the circular API service symbol.



Brake Fluid

Do not add or replace brake fluid, except in an emergency. Use only fresh brake fluid from a sealed container. If you do add fluid, have the brake system serviced by your dealer as soon as possible.

NOTICE

Brake fluid can damage plastic and painted surfaces. Wipe up spills immediately and wash thoroughly.

Recommended brake fluid:

Honda DOT 3 or DOT 4 Brake Fluid or equivalent

Recommended Coolant

Use only genuine Honda PRE-MIX COOLANT without diluting with water. Genuine Honda PRE-MIX COOLANT is excellent at preventing corrosion and overheating.

The coolant should be inspected and replaced properly by following the maintenance schedule.

➤ P. 57

NOTICE

Using coolant not specified for aluminium engines or tap/mineral water can cause corrosion.

Crankcase Breather

Service more frequently when riding in rain, at full throttle, or after the scooter is washed or overturned. Service if the deposit level can be seen in the transparent section of the drain tube. If the drain tube overflows, the air filter may become contaminated with engine oil causing poor engine performance. ➤ P. 88

Maintenance Fundamentals


Tyres (Inspecting/Replacing)

■ Checking the Air Pressure

Visually inspect your tyres and use an air pressure gauge to measure the air pressure at least once a month or any time you think the tyres look low. Always check air pressure when your tyres are cold.


■ Inspecting for Damage

Inspect the tyres for cuts, slits, or cracks that exposes fabric or cords, or nails or other foreign objects embedded in the side of the tyre or the tread. Also inspect for any unusual bumps or bulges in the side walls of the tyres.




■ Inspecting for Abnormal Wear

Inspect the tyres for signs of abnormal wear on the contact surface.



Inspecting Tread Depth

Inspect the tread wear indicators. If they become visible, replace the tyres immediately.



! WARNING

Riding on tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.

Maintenance Fundamentals

Have your tyres replaced by your dealer.
For recommended tyres and air pressure, see
"Specifications." ➤ P. 119

Follow these guidelines whenever you replace
tyres.

- Use the recommended tyres or equivalents of the same size, construction, speed rating, and load range.
- Do not install a tube inside a tubeless tyre on this scooter. Excessive heat build-up can cause the tube to burst.
- Use only tubeless tyres on this scooter. The rims are designed for tubeless tyres, and during hard acceleration or braking, a tubetype tyre could slip on the rim and cause the tyre to rapidly deflate.

WARNING

Installing improper tyres on your scooter can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tyres recommended in this owner's manual.

Air Cleaner

This scooter is equipped with a viscous type air cleaner element.

Air blow cleaning or any other cleaning can degrade the viscous element performance and cause the intake of dust.

Do not perform the maintenance.

Should be serviced by your dealer.



Tool

The tools are in reverse side of the seat.



➡ P. 53

You can perform some roadside repairs, minor adjustments and parts replacement with the provided tools.

- Spark plug wrench
- Standard/Phillips screwdriver
- Screwdriver handle

Removing & Installing Body Components

Battery



Removal

Make sure the ignition switch is in the **O** (Off) position.

1. Remove the battery lid from step floor by removing the screw.
2. Remove the service coupler from the battery cover guide.

continued 71

Removing & Installing Body Components ► Battery

3. Remove the battery cover from step floor.
4. Disconnect the negative $\ominus$ terminal from the battery.
5. Disconnect the positive $\oplus$ terminal from the battery.
6. Remove the battery taking care not to drop the terminal nuts.

Installation

Install the parts in the reverse order of removal. Always connect the positive $\oplus$ terminal first. Make sure that bolts and nuts are tight.

Make sure the clock information is correct after the battery is reconnected. ► P. 20

ACB125CBT

The anti-theft alarm system will be deactivated if the battery is disconnected. The system will remain off when the battery is reconnected.

For proper handling of the battery, see "Maintenance Fundamentals." ► P. 60

"Battery Goes Dead." ► P. 101

Checking the Spark Plug


For the recommended spark plug, see "Specifications." ▣ P. 119

Use only the recommended type of spark plug in the recommended heat range.

NOTICE

Using a spark plug with an improper heat range can cause engine damage.

1. Place your scooter on the centre stand on a level surface.
2. Disconnect the spark plug cap from the spark plug.
3. Clean any dirt from around the spark plug base.
4. Remove the spark plug using provided spark plug wrench. ▣ P. 70




5. Inspect the electrodes and centre porcelain for deposits, erosion or carbon fouling.
 - ▶ If the erosion or deposit is heavy, replace the plug.
 - ▶ Clean a carbon or wet-fouled plug with a plug cleaner, otherwise use a wire brush.

Spark Plug ► Checking the Spark Plug

6. Check the spark plug gap using a wire type feeler gauge.
► If adjustment is necessary, bend the side electrode carefully.

The gap should be:

0.8 to 0.9 mm (0.03 to 0.04 in)



7. Make sure the plug washer is in good condition.
8. Install the spark plug. With the plug washer attached, thread the spark plug in by hand to prevent cross-threading.

9. Tighten the spark plug:

- If the old plug is good: 1/8 turn after it seats.
- If installing a new plug tighten it twice to prevent loosening
 - a) First, tighten the plug:
NGK: 1/2 turn after it seats.
DENSO: 3/4 turn after it seats.
 - b) Then loosen the plug.
 - c) Next, tighten the plug again:
1/8 turn after it seats.

NOTICE

An improperly tightened spark plug can damage the engine. If a plug is too loose, a piston may be damaged. If a plug is too tight, the threads may be damaged.


10. Install the parts in the reverse order of removal.
► When reinstalling the spark plug cap, take care to avoid pinching any cables or wires.

Checking the Engine Oil

ACB125CBT

Check the engine oil with the Idling Stop switch at IDLING.

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch to the **○** (Off) position and wait for 2 to 3 minutes.
3. Place your scooter on its centre stand on a firm, level surface.
4. Remove the oil fill cap/dipstick and wipe it clean.
5. Insert the oil fill cap/dipstick until it seats, but don't screw it in.
6. Check that the oil level is between the upper level and lower level marks on the oil fill cap/dipstick.
7. Securely install the oil fill cap/dipstick.



Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil.

► P. 64, 119

1. Remove the oil fill cap/dipstick. Add the recommended oil until it reaches the upper level mark.
 - Place your scooter on its centre stand on a firm, level surface when checking the oil level.
 - Do not overfill above the upper level mark.
 - Make sure no foreign objects enter the oil filler opening.
 - Wipe up any spills immediately.
2. Securely reinstall the oil fill cap/dipstick.

NOTICE

Overfilling with oil or operating with insufficient oil can cause damage to your engine. Do not mix different brands and grades of oil.

For the recommended oil and oil selection guidelines, see "Maintenance Fundamentals."

► P. 64

Changing Engine Oil, Cleaning Strainer Screen

Changing the oil and cleaning the strainer screen requires special tools. We recommend that you have your scooter serviced by your dealer.



ACB125CBT

Change the engine oil with the Idling Stop switch at IDLING.

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch to the **○** (Off) position and wait for 2 to 3 minutes.

3. Place your scooter on its centre stand on a firm, level surface.
4. Place a drain pan under the drain bolt and oil plug.
5. Remove the oil fill cap/dipstick, drain bolt and sealing washer to drain the oil.
6. Remove the oil plug, O-ring, spring and oil strainer screen and let the remaining oil drain out.
 - Discard the oil at an approved recycling centre.
7. Clean the oil strainer screen.
8. Check that the oil strainer screen and sealing rubber are in good condition.
9. Replace the O-ring and apply a thin coat of engine oil to the new O-ring before installing it.
10. Install the oil strainer screen, spring and oil plug and tighten.

Torque: 20 N·m (2.0 kgf·m, 15 lbf·ft)



Engine Oil ► Changing Engine Oil, Cleaning Strainer Screen

- 11.** Install a new sealing washer onto the drain bolt. Tighten the drain bolt.

Torque: 24 N·m (2.4 kgf·m, 18 lbf·ft)

- 12.** Fill the crankcase with the recommended oil (► P. 64, 119) and install the oil fill cap/dipstick.

Required oil

When changing oil & cleaning the strainer screen:

0.8 litres (0.8 US qt, 0.7 Imp qt)

When changing oil only:


0.8 litres (0.8 US qt, 0.7 Imp qt)

- 13.** Check the oil level. ► P. 75
- 14.** Check that there are no oil leaks.

Checking the Coolant

Check that the coolant level in the reserve tank while the engine is cold.

1. Place your scooter on a firm, level surface.
2. Hold your scooter in an upright position.
3. Check that the coolant level is between the UPPER level and LOWER level marks on the reserve tank.



If the coolant level is dropping noticeably or the reserve tank is empty, you likely have a serious leak. Have your scooter inspected by your dealer.

Adding Coolant

If the coolant level is below the LOWER level mark, add the recommended coolant (P. 65) until the level reaches the UPPER level mark.

Add fluid only from the reserve tank cap and do not remove the radiator cap.

1. Remove the reserve tank cover by removing the screw.
2. Remove the reserve tank cap and add fluid while monitoring the coolant level.
 - ▶ Do not overfill above the UPPER level mark.
 - ▶ Make sure no foreign objects enter the reserve tank opening.


Coolant ► Changing Coolant

3. Securely reinstall the reserve tank cap.
4. Install the removed parts in the reverse order of removal.

⚠ WARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, potentially scalding you.

Always let the engine and radiator cool down before removing the radiator cap.


**Changing Coolant**

Have your dealer change the coolant unless you have the proper tools and are mechanically qualified.

Checking the Front Brake Fluid

1. Place your scooter in an upright position on a firm, level surface.
2. Check that the brake fluid reservoir is horizontal and that the fluid level is above the LWR mark.

If the brake fluid level in the reservoir is below the LWR mark or the brake lever freeplay becomes excessive, inspect the brake pads for wear. If the brake pads are not worn, you most likely have a leak. Have your scooter inspected by your dealer.




Brakes ► Inspecting the Front Brake Pads

Inspecting the Front Brake Pads

Check the condition of the brake pad wear indicators.

The pads need to be replaced if a brake pad is worn to the indicator.



Inspect the brake pads from below the brake caliper.

If necessary have the pads replaced by your dealer.


Always replace both left and right brake pads at the same time.

Inspecting the Rear Brake Lever Freeplay

1. Place the scooter on its centre stand.
2. Measure the distance the rear brake lever moves before the brake takes hold.

Freeplay at the tip of the brake lever:

10 to 20 mm (0.4 to 0.8 in)



Brakes ► Adjusting the Rear Brake Lever Freeplay

Check the brake cable for kinks or signs of wear. If necessary have it replaced by your dealer.


Lubricate the brake cable with a commercially available cable lubricant to prevent premature wear and corrosion.

Make sure the brake arm, spring and fastener are in good condition.

Adjusting the Rear Brake Lever Freeplay

Adjust the freeplay of the brake lever with the front wheel pointed straight ahead.


Make sure the cut-out on the adjusting nut is seated on the brake arm pin when adjusting the freeplay.



If proper adjustment cannot be obtained by this method, see your dealer.


Brakes ► Adjusting the Rear Brake Lever Freeplay

1. Adjust by turning the rear brake adjusting nut a half-turn at a time.



2. Apply the brake several times and check for free wheel rotation after the brake lever is released.

3. Push the brake arm to confirm that there is a gap between the rear brake adjusting nut and brake arm pin.



After adjustment, confirm the freeplay of the brake lever.


NOTICE

Do not turn the adjuster beyond its natural limits.

Brakes ► Inspecting the Rear Brake Shoe Wear

Inspecting the Rear Brake Shoe Wear


The rear brake is equipped with a brake wear indicator.



When the brake is applied, an arrow attached to the brake arm moves toward a reference mark on the brake panel. If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced. See your dealer for this service.

When the brake service is necessary, see your dealer. Use only Honda Genuine Parts or its equivalent.

Checking the Side Stand



1. Place your scooter on its centre stand on a firm, level surface.
2. Check that the side stand operates smoothly. If the side stand is stiff or squeaky, clean the pivot area and lubricate the pivot bolt with clean grease.
3. Check the spring for damage or loss of tension.
4. Sit on the scooter and raise the side stand.
5. Start the engine.
6. Lower the side stand all the way. The engine should stop as you lower the side stand. If the engine doesn't stop, have your scooter inspected by your dealer.


Throttle

Checking the Throttle

With the engine off, check that the throttle rotates smoothly from fully closed to fully open in all steering positions and throttle freeplay is correct. If the throttle does not move smoothly, close automatically, or if the cable is damaged, have the scooter inspected by your dealer.


Freeplay at the throttle grip flange:

2 to 6 mm (0.1 to 0.2 in)



Cleaning the Crankcase Breather

1. Place a suitable container under the crankcase breather tube.
2. Remove the crankcase breather tube and drain deposits.
3. Reinstall the crankcase breather tube.




Adjusting the Headlight Aim

The right and left headlight aim can be adjusted in the same way.

You can adjust vertical aim of the headlights for proper alignment. Turn the pinion in or out as necessary using provided Phillips screwdriver (➡ P. 70).

Obey local laws and regulations.




Replacing the Remote Transmitter Battery

When the remote transmitter battery begins to get weak, it may take several pushes on the button to operate the anti-theft alarm system or answer back system, and the LED will get dim. Replace the battery as soon as possible. We recommend to see your dealer for this service.

Battery type: CR1632

1. Remove the upper case by carefully prying on the edge with a coin or a screw driver.
 - ▶ Wrap a coin or a screwdriver with a protective cloth to prevent scratching the remote transmitter.
 - ▶ Do not touch the circuit or terminal. This may cause problems.
 - ▶ Be careful to avoid scratching the waterproof covering or allowing dust to enter.
 - ▶ Do not forcibly dismantle the remote transmitter body.

2. Replace the old battery with a new battery with the negative $\ominus$ side facing up.
3. Snap the two halves of the remote transmitter back together.
► Make sure that upper and lower cases are set in the right position.



⚠ WARNING

Chemical Burn Hazard: do not swallow battery.

If swallowed, the battery can cause severe internal burns and even death.

- Keep battery away from children and battery compartment securely closed.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- Immediately seek medical attention if a child may have swallowed battery.

Troubleshooting

Engine Will Not Start	P. 93
Overheating (High coolant temperature indicator is on)	P. 94
Warning Indicators On or Flashing	P. 95
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL).....	P. 95
Battery Charging Condition Indicator	P. 95
Other Warning Indications	P. 96
Fuel Gauge Failure Indication.....	P. 96
When the Idling Stop System Does Not Operate Properly	P. 97
Idling Stop Indicator Does Not Come On	P. 97

Engine is Not Stopped by the Idling Stop System While the Idling Stop Indicator is On	P. 98
Engine Does Not Start Even If the Throttle is Opened.....	P. 99
Tyre Puncture	P. 100
Electrical Trouble	P. 101
Battery Goes Dead	P. 101
Burned-out Light Bulb.....	P. 101
Blown Fuse	P. 103
Unstable Engine Operation Occurs Intermittently	P. 104

Engine Will Not Start

Starter Motor Operates But Engine Does Not Start

Check the following items:

- Check the correct engine starting sequence.
➡ P. 43
- Check that there is petrol in the fuel tank.
- Check if the PGM-FI malfunction indicator lamp (MIL) is on.
▶ If the indicator lamp is on, contact your dealer as soon as possible.

Starter Motor Does Not Operate

Check the following items:

- Check the correct engine starting sequence.
➡ P. 43
- Check for a blown fuse. ➡ P. 103
- Check for a loose battery connection (➡ P. 71) or battery terminal corrosion (➡ P. 62).
- Check the condition of the battery. ➡ P. 101

If the problem continues, have your scooter inspected by your dealer.

Overheating (High coolant temperature indicator is on)

The engine is overheating when the following occurs:

- High coolant temperature indicator comes on.
- Acceleration becomes sluggish.

If this occurs, pull safely to the side of the road and perform the following procedure. Extended fast idling may cause the high coolant temperature indicator to come on.

NOTICE

Continuing to ride with an overheated engine can cause serious damage to the engine.

1. Stop the engine using the ignition switch.
2. Allow the engine to cool with the ignition switch in the  (Off) position.
3. After the engine has cooled, inspect the radiator hose and check if there is a leak.
 P. 79
If there is a leak:
Do not start the engine. Transport your scooter to your dealer.
4. Check the coolant level in the reserve tank.
 P. 79
▶ Add coolant as necessary.
5. If 1-4 check normal, you may continue riding, but closely monitor the high coolant temperature indicator.

Warning Indicators On or Flashing

PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL)

If the indicator comes on while riding, you may have a serious problem with the PGM-FI system. Reduce speed and have your scooter inspected by your dealer as soon as possible.

Battery Charging Condition Indicator

If the indicator comes on while riding, you may have a condition of low battery voltage or battery performance degradation. Have your scooter inspected by your dealer.


► If the battery does not have enough voltage to drive the indicator system, the indicator may not come on.

Other Warning Indications

Fuel Gauge Failure Indication

If the fuel system has an error, the fuel gauge indicators will be displayed as shown in the illustration.

If these occur, see your dealer as soon as possible.



When the Idling Stop System Does Not Operate Properly

Idling Stop Indicator Does Not Come On ACB125CBT

When the Idling Stop indicator does not come on, perform the followings.

If the Idling Stop switch is at IDLING:

Press the Idling Stop switch to IDLING STOP.

If the engine is cold:

Warm up the engine.

The Idling Stop system does not operate when the engine is cold.

If you did not ride the scooter after engine starts:

Ride the scooter at speeds of over 10 km/h (6 mph). The Idling Stop system does not operate until you ride once.

If PGM-FI malfunction indicator lamp (MIL) lights:

When the PGM-FI malfunction indicator lamp (MIL) lights, the Idling Stop system does not operate for protection of the engine. See your dealer.

If the battery voltage is low:

Ride the scooter awhile, then stop the engine and then restart the engine with the start button, referring to the starting procedure (P. 43) for standard engine starting. The Idling Stop system may not operate if the battery voltage is low.

If this occurs frequently, contact your dealer.

Engine is Not Stopped by the Idling Stop System While the Idling Stop Indicator is On

ACB125CBT

When the engine is not stopped by Idling Stop system while the Idling Stop indicator is on, perform the followings.

If the scooter does not stop completely:

Stop the scooter completely. The Idling Stop system operates if the speed is only at 0 km/h (0 mph).

If the throttle is not closed completely:

Close the throttle completely.

Engine Does Not Start Even If the Throttle is Opened **ACB125CBT**

Engine does not start even if the throttle is opened, perform the followings.

If the side stand is down:

While the engine is stopped by the Idling Stop system, if you operate the side stand, the flashing Idling Stop indicator turns off or stops flashing and stays on, and the Idling Stop system is cancelled. Restart the engine with the start button, referring to the starting procedure (► P. 43) for standard engine starting.

If the Idling Stop switch is at IDLING:

While the engine is stopping by the Idling Stop system, if you press the Idling Stop switch to IDLING, the Idling Stop system will be cancelled. Restart the engine with the start button, referring to the starting procedure (► P. 43) for standard engine starting.

If the Idling Stop indicator flashes (the Idling Stop switch is at IDLING STOP position), but engine does not start even if the throttle is opened, perform the followings.

Low (or dead) battery or battery lead is loose:

Check the battery and battery terminals. If the battery is weak, contact your dealer.

Tyre Puncture

Repairing a puncture or removing a wheel requires special tools and technical expertise. We recommend you have this type of service performed by your dealer.

After an emergency repair, always have the tyre inspected/replaced by your dealer.

Emergency Repair Using a Tyre Repair Kit

If your tyre has a minor puncture, you can make an emergency repair using a tubeless tyre repair kit.

Follow the instructions provided with the emergency tyre repair kit.

Riding your scooter with a temporary tyre repair is very risky. Do not exceed 50 km/h (30 mph). Have the tyre replaced by your dealer as soon as possible.

WARNING

Riding your scooter with a temporary tyre repair can be risky. If the temporary repair fails, you can crash and be seriously injured or killed.

If you must ride with a temporary tyre repair, ride slowly and carefully and do not exceed 50 km/h (30 mph) until the tyre is replaced.

Battery Goes Dead

Charge the battery using a motorcycle battery charger.

Remove the battery from the scooter before charging.

Do not use an automobile-type battery charger, as these can overheat a scooter battery and cause permanent damage.

If the battery does not recover after recharging, contact your dealer.


NOTICE

Jump starting using an automobile battery can damage your scooter's electrical system and is not recommended.

Burned-out Light Bulb

All light bulbs on the scooter's are LEDs. If there is an LED which is not turned on, see your dealer for servicing.


Headlight/Front Turn Signal Light/Position Light



The headlight/front turn signal light/position light use several LEDs.

If there is an LED which is not turned on, see your dealer for this servicing.

Brakelight/Taillight/Rear Turn Signal Light/License Plate Light




The brakelight/taillight/rear turn signal light/license plate light use several LEDs.

If there is an LED which is not turned on, see your dealer for this servicing.

Blown Fuse

Before handling fuses, see "Inspecting and Replacing Fuses." ► P. 63

Fuse Box Fuses



1. Remove the battery lid and the battery cover from the step floor. ► P. 71
2. Pull out the fuses one by one to check for a blown fuse. Always replace a blown fuse with a spare of the same rating.
► Spare fuses are provided on the reverse side of the battery cover.
3. Install the battery lid and the battery cover.

NOTICE

If a fuse fails repeatedly, you likely have an electrical problem. Have your scooter inspected by your dealer.

Unstable Engine Operation Occurs Intermittently

If the fuel pump filter is clogged, unstable engine operation will occur intermittently while riding.

Even if this symptom occurs, you can continue to ride your scooter.

If unstable engine operation occurs even if sufficient fuel is available, have your scooter inspected by your dealer as soon as possible.

Information

Keys	P. 106
Instruments, Controls, & Other Features ...	P. 109
Caring for Your Scooter	P. 110
Storing Your Scooter	P. 113
Transporting Your Scooter	P. 113
You & the Environment	P. 114
Serial Numbers.....	P. 115
Fuels Containing Alcohol	P. 116
Catalytic Converter	P. 117

Keys

Ignition Key

Be sure to record the key number provided with the original keys and record it in this manual.

Store the spare key in a safe location.

To make a duplicate, take the spare key or the key number to your dealer.

If you lose all keys and the key number, the ignition switch assembly will probably have to be removed by your dealer to determine the key number.

A metal key holder may cause damage to the area surrounding the ignition switch.

Remote Transmitter

The remote transmitter contains electronic circuits that are activated by the anti-theft alarm system and answer back system. If the circuits are damaged, the remote transmitter will not be able to operate the anti-theft alarm system and answer back system.

- Do not drop the remote transmitter or set heavy objects on them.
- Protect the remote transmitter from direct sunlight, high temperature, and high humidity.
- Do not scratch or puncture.
- Do not store near any magnetized products such as a magnetized key chain.

- Always keep the remote transmitter away from electric appliances such as a TV, radio, PC or low-frequency massage device.
- Keep the remote transmitter away from liquids. If it gets wet, dry them immediately with a soft cloth.
- Keep the remote transmitter away from the scooter while washing the scooter.
- Do not burn.
- Do not wash in the ultrasonic cleaner.
- If fuel, wax, or grease adhere to the remote transmitter, wipe it off immediately to avoid cracking or warping.
- Do not disassemble the remote transmitter other than when changing a battery. Only the cover of the remote transmitter can be disassembled. Do not disassemble other parts.
- Do not lose your remote transmitter. If you lose it, you will need to register a new remote transmitter. See your dealer for registration.

The anti-theft alarm system and answer back system may not work properly in the following environments:

- There is strong electrical current nearby.
- You carry a cell phone, a laptop computer, or other electrical device.
- The remote transmitter is touching or covered by metal.

The battery in the remote transmitter normally lasts about 2 years.

Do not keep mobile phones or other radio transmitting devices in luggage box. The radio frequency from the devices will interrupt the anti-theft alarm system and answer back system.

You should always keep the remote transmitter on your person.

Anyone in possession of the remote transmitter can operate the answer back system and anti-theft alarm system.

Keys

To add an additional remote transmitter, take the remote transmitter and the scooter to your dealer.

The remote transmitter uses low-intensity radio waves, so the operating range can be wider or narrower according to the circumstances.

Instruments, Controls, & Other Features

Ignition Switch

Leaving the ignition switch in the **I** (On) position with the engine stopped will drain the battery.

Do not turn the key while riding.

Odometer

The display locks at 999,999 when the read-out exceeds 999,999.

Tripmeter

The tripmeters return to 0.0 when each read-out exceeds 999.9.

Also average fuel mileage is reset at the same time when the tripmeter A is reset.

Document Bag

The owner's manual, registration, and insurance information can be stored in the plastic document bag reverse side of the seat.

Caring for Your Scooter

Caring for Your Scooter

Frequent cleaning and polishing is important to ensure the life of your Honda. A clean scooter makes it easier to spot potential problems. In particular, seawater and salts used to prevent ice on roads promote the formation of corrosion. Always wash your scooter thoroughly after riding on coastal or treated roads.

Washing

Allow the engine, muffler, brakes, and other high-temperature parts to cool before washing.

1. Rinse your scooter thoroughly using a low pressure garden hose to remove loose dirt.
2. If necessary, use a sponge or a soft towel with mild cleaner to remove road grime.
 - Clean the headlight lens, panels, and other plastic components with extra care to avoid scratching them. Avoid directing water into the air cleaner, muffler, and electrical parts.

3. Thoroughly rinse your scooter with plenty of clean water and dry with a soft, clean cloth.
4. After the scooter dries, lubricate any moving parts.
 - Make sure that no lubricant spills onto the brakes or tyres. Brake disc, pads, drum or shoes contaminated with oil will suffer greatly reduced braking effectiveness and can lead to a crash.
5. Apply a coat of wax to prevent corrosion.
 - Avoid products that contain harsh detergents or chemical solvents. These can damage the metal, paint, and plastic on your scooter.
Keep the wax clear of the tyres and brakes.
 - If your scooter has any mat painted parts, do not apply a coat of wax to the mat painted surface.

Washing Precautions

Follow these guidelines when washing:

- Do not use high-pressure washers:
 - ▶ High-pressure water cleaners can damage moving parts and electrical parts, rendering them inoperable.
 - ▶ Water in the air intake can be drawn into the throttle body and/or enter the air cleaner.
- Do not direct water at the muffler:
 - ▶ Water in the muffler can prevent starting and causes rust in the muffler.
- Dry the brakes:
 - ▶ Water adversely affects braking effectiveness. After washing, apply the brakes intermittently at low speed to help dry them.
- Do not direct water under the seat:
 - ▶ Water in the under seat compartment can damage your documents and other belongings.
- Do not direct water at the air cleaner:
 - ▶ Water in the air cleaner can prevent the engine from starting.

- Do not direct water near the headlight:
 - ▶ The headlight's inside lens may fog temporarily after washing or while riding in the rain. This does not impact the headlight function.
However, if you see a large amount of water or ice accumulated inside the lens(es), have your vehicle inspected by your dealer.
- Do not use wax or polishing compounds on mat painted surface:
 - ▶ Use soft cloth or sponge, plenty of water, and a mild detergent to clean mat painted surfaces. Dry with a soft clean cloth.

Aluminium Components

Aluminium will corrode from contact with dirt, mud, or road salt. Clean aluminium parts regularly and follow these guidelines to avoid scratches:

- Do not use stiff brushes, steel wool, or cleaners containing abrasives.
- Avoid riding over or scraping against curbs.

Caring for Your Scooter

Panels

Follow these guidelines to prevent scratches and blemishes:

- Wash gently using a soft sponge and plenty of water.
- To remove stubborn stains, use diluted detergent and rinse thoroughly with plenty of water.
- Avoid getting petrol, brake fluid, or detergents on the instruments, panels, or headlights.

Exhaust Pipe and Muffler

When the exhaust pipe and muffler are painted, do not use a commercially available abrasive kitchen cleaning compound. Use a neutral detergent to clean the painted surface on the exhaust pipe and muffler. If you are not sure if your exhaust pipe and muffler are painted, contact your dealer.

Storing Your Scooter

If you store your scooter outdoors, you should consider using a full-body scooter cover.

If you won't be riding for an extended period, follow these guidelines:

- Wash your scooter and wax all painted surfaces (except mat painted surfaces). Coat chrome pieces with rust-inhibiting oil.
- Place your scooter on its centre stand and position a block so that both tyres are off the ground.
- After rain, remove the body cover and allow the scooter to dry.
- Remove the battery (➡ P. 71) to prevent discharge.
Fully charge the battery and then place it in a shaded, well-ventilated area.
 - ▶ If you leave the battery in place, disconnect the negative ⊖ terminal to prevent discharge.

After removing your scooter from storage, inspect all maintenance items required by the Maintenance Schedule.

Transporting Your Scooter

If your scooter needs to be transported, it should be carried on a motorcycle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform, and motorcycle tie-down straps. Never try to tow your scooter with a wheel or wheels on the ground.

NOTICE

Towing your scooter can cause serious damage to the transmission.

You & the Environment

Owning and riding a scooter can be enjoyable, but you must do your part to protect the environment.

Choose Sensible Cleaners

Use a biodegradable detergent when you wash your scooter. Avoid aerosol spray cleaners that contain chlorofluorocarbons (CFCs) which damage the atmosphere's protective ozone layer.

Recycle Wastes


Put oil and other toxic wastes in approved containers and take them to a recycling centre. Call your local or state office of public works or environmental services to find a recycling centre in your area, and to get instructions on how to dispose of non-recyclable wastes. Do not place used engine oil in the trash, or pour it down a

drain or on the ground. Used oil, petrol, coolant, and cleaning solvents contain poisons that can hurt refuse workers and contaminate drinking water, lakes, rivers, and oceans.


Serial Numbers

The frame and engine serial numbers uniquely identify your scooter and are required in order to register your scooter. They may also be required when ordering replacement parts. You should record these numbers and keep them in a safe place.

Frame number



Engine number



Fuels Containing Alcohol

Fuels Containing Alcohol

Some conventional fuels blended with alcohol are available in some locales to help reduce emissions to meet clean air standards. If you plan to use blended fuel, check that it is unleaded and meets the minimum octane rating requirement.

The following fuel blends can be used in your scooter:

- Ethanol (ethyl alcohol) up to 10% by volume.
 - ▶ Petrol containing ethanol may be marketed under the name Gasohol.

The use of petrol containing more than 10% ethanol may:

- Damage the painting of the fuel tank.
- Damage the rubber tubes of the fuel line.
- Cause corrosion of the fuel tank.
- Cause poor drivability.

NOTICE

Use of blended fuels containing higher than approved percentages can damage metal, rubber, plastic parts of your fuel system.

If you notice any undesirable operating symptoms or performance problems, try a different brand of petrol.

Catalytic Converter

This scooter is equipped with a three-way catalytic converter. The catalytic converter contains precious metals that serve as catalysts in high temperature chemical reactions that convert hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx) in the exhaust gasses into safe compounds.

A defective catalytic converter contributes to air pollution and can impair your engine's performance. A replacement unit must be an original Honda part or equivalent.

Follow these guidelines to protect your scooter's catalytic converter.

- Always use unleaded petrol. Leaded petrol will damage the catalytic converter.
- Keep the engine in good running condition.
- Have your scooter serviced if your engine is misfiring, backfiring, stalling, or otherwise not running properly, stop riding and turn off the engine.

Specifications

■ Main Components

Overall length	1,919 mm (75.6 in)
Overall width	679 mm (26.7 in)
Overall height	1,062 mm (41.8 in)
Wheelbase	1,280 mm (50.4 in)
Minimum ground clearance	132 mm (5.2 in)
Caster angle	26° 30'
Trail	83 mm (3.3 in)
Curb weight	111 kg (245 lb)
Maximum weight capacity*1	122 kg (269 lb)
Maximum luggage weight*2	Luggage box 10 kg (22 lb)
	Hook and glove box 1.5 kg (3.3 lb)
Passenger capacity	Rider and 1 passenger
Minimum turning radius	1.90 m (6.23 ft)

*1 Including rider, passenger, all luggage, and accessories.

*2 Includes the weight of the luggage and added accessories.

Displacement	IN type
	124.88 cm ³ (7.618 cu-in)
	PH type
	124 cm ³ (7.6 cu-in)
Bore × stroke	52.400 × 57.907 mm (2.0630 × 2.2798 cu-in)
Compression ratio	11.0:1
Fuel	Unleaded petrol Recommended: 88 RON or higher
Fuel containing alcohol	ETHANOL up to 10 % by volume
Tank capacity	5.5 litres (1.45 US gal, 1.21 Imp gal)
Battery	IN type
	GTZ6V or YTZ6V
	PH type
	GTZ6V
	12 V-5 Ah (10 HR)
Primary reduction	V-Matic (2.60:1-0.82:1)
Final reduction	10.552

■ Service Data

Tyre size	Front	80/90-14M/C 40P
	Rear	90/90-14M/C 46P
Tyre type		Bias-ply, tubeless
Recommended Tyres	Front	IN type SRI FT235 or IRC NF66 PH type SRI FT235
	Rear	IN type SRI FT235 or IRC NR83 PH type SRI FT235
Tyre air pressure		[Driver only]
	Front	200 kPa (2.00 kgf/cm ² , 29 psi) [Driver and passenger]
		200 kPa (2.00 kgf/cm ² , 29 psi)
		[Driver only]
	Rear	225 kPa (2.25 kgf/cm ² , 33 psi) [Driver and passenger]
		225 kPa (2.25 kgf/cm ² , 33 psi)
Spark plug	(standard)	CPR9EA-9 (NGK) U27EPR9 (DENSO)
Spark plug gap		0.8 to 0.9 mm (0.03 to 0.04 in)
Idle speed		1,700 ± 100 rpm
Recommended engine oil		Honda 4-stroke motorcycle oil API Service Classification SG or higher, excluding oils marked as "Energy Conserving" or "Resource Conserving," SAE 10W-30, JASO T 903 standard MB

Engine oil capacity	After draining	0.8 litres (0.8 US qt, 0.7 Imp qt)
	After draining & engine oil filter change	0.8 litres (0.8 US qt, 0.7 Imp qt)
	After disassembly	0.9 litres (1.0 US qt, 0.8 Imp qt)
Transmission oil capacity	After draining	0.12 litres (0.13 US qt, 0.11 Imp qt)
	After disassembly	0.14 litres (0.15 US qt, 0.12 Imp qt)
Recommended brake fluid		Honda DOT 3 or DOT 4 Brake Fluid
Cooling system capacity		0.51 litres (0.54 US qt, 0.45 Imp qt)
Recommended coolant		Honda PRE-MIX COOLANT

Specifications

■ Bulbs

Headlight	LED
Brakelight/Taillight	LED
Front turn signal light	LED
Rear turn signal light	LED
License plate light	LED
Position light	LED

■ Fuses

Main fuse	25 A
Other fuse	10 A

■ Torque Specifications

Engine oil drain bolt	24 N·m (2.4 kgf·m, 18 lbf·ft)
Oil plug	20 N·m (2.0 kgf·m, 15 lbf·ft)

A

Accessories	10
Answer Back System	34
Anti-theft Alarm System	30

B

Basic Operation Flow	12
Battery	61, 71
Brakes	
Fluid	65, 81
Front Pad Wear	82
Rear Brake Lever Freeplay	82
Rear Brake Shoe Wear	85
Braking	7

C

Caring for Your Scooter	110
Catalytic Converter	117
Clock	17
Compartment	
Document Bag	53, 109
Owner's Manual	53, 109
Tool	53, 70

Coolant	65, 79
Crankcase Breather	88

D

Digital Clock Adjustment	21
Document Bag	53, 109

E

Electrical Trouble	101
Engine	
Number	115
Oil	64, 75
Overheats	94
Starting	43
Environment	114

F

Flooded Engine	46
Frame Number	115
Fuel	
Gauge	17
Mileage Meter	18
Recommended	49

Remaining	17
Tank Capacity	49
Fuels Containing Alcohol	116
Fuses	63, 103

G

Gasohol	116
---------------	-----

H

Headlight Aim	89
Headlight Dimmer Switch	26
Helmet Holder	52
High Coolant Temperature Indicator	24, 94
Horn Button	26

I

Idling Stop Indicator	25
Idling Stop Switch	26
Idling Stop System	40
Ignition Cut-off System	
Side Stand	86
Ignition Switch	27, 109
Indicators	24

Instruments	16
-------------------	----

K

Key	106
-----------	-----

L

Load Limits	11
Loading Guidelines	11
Luggage Box	53

M

Maintenance	
Fundamentals	60
Importance	56
Safety	56
Schedule	57
Maximum Weight Limit	11, 118
Modifications	10

O

Odometer	17, 109
----------------	---------

Oil	
Engine	64, 75
Overheating	94

P

Parking	8
Parts Location	14
Petrol	9, 49, 118
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL)	24, 95
Protective Apparel	6

R

Rear Brake Lock	39
Recommended	
Coolant	65
Fuel	49
Oil	64
Refuelling	49
Removal	
Battery	71
Repair Kit	100
Riding Precautions	7

S

Safety Precautions	6
Seat	51
Serial Numbers	115
Shutter	29
Side Stand	86
Side Stand Ignition Cut-off System	43, 86
Spark Plug	73, 119
Specifications	118
Speedometer	16
Start Button	26, 45
Starting the Engine	43
Starting the Scooter	47
Steering Lock	28
Storage	
Equipment	51
Hook	54
Luggage Box	53
Owner's Manual	53, 109
Storing Your Scooter	113
Switches	26

T

Throttle	87
Tool	53, 70
Transmitter Unit Battery	90
Transporting Your Scooter	113
Tripmeter	109
Troubleshooting	92
Turn Signal Indicators	24
Tyres	
Air Pressure	66, 119
Puncture	100
Replacing	66, 100

W

Warning Indicator On	95
Washing Your Scooter	110
Weight Limit	11



For Comments and Suggestions you may contact us at:

Honda Philippines, Inc.

Head Office & Manufacturing Plant

Lot 34 Phase 1 - B Road 3,

First Philippine Industrial Park,

Tanauan City 4234 Batangas

Tel. Nos. (632) 581-6700 to 99

Tel. Nos. (632) 756-7300 to 59

Email : customerservice@hondaph.com

Website: www.hondaph.com

32K60A100

PRINTED IN THE PHILIPPINES