

DEFLECTOR B

Accessory Name	Parts Number	Application Model	Issue Date	Publication No.	FRT
DEFLECTOR B	08R02-MLT-D00	CB1000GT	2025.09	MII	0.1 H

Introduction

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON Honda MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

Honda Dealer:

Please give a copy of these instructions to your customer.

Customer:

Because it requires specialized knowledge and special tools and equipment, it is recommended to install it at a dealer with qualified automobile maintenance.

How To Read These Symbols

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual.

-  **WARNING** You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.
-  **CAUTION** You CAN be HURT if you don't follow instructions.
-  **NOTICE** The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.
-  **NOTE** Things you want to know, things that are useful to know.
-  Follow the instructions of the Service Manual.
-  Follow the other symbol instructions of the "Installation Instructions BASIC".

Instruction Other Symbols

The symbols used throughout this instructions show specific service procedures. Refer to "Installation Instructions BASIC" for description of each symbol.

INFORMATION

CAUTION

- To prevent burns, allow the engine, exhaust system, radiator, etc., to cool before installing the accessory.

NOTICE

- Take care not to damage the painted surfaces of the motorcycle.

NOTE:


- Heat the bonding surfaces with a hair dryer if the ambient air temperature is below 21°C (70°F).
- The adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.
- Save all removed parts unless otherwise indicated.

TORQUE INFORMATION



Refer to the Service Manual for the torque values including standard torque of the removed parts. ()

PARTS LIST

When the instruction manual and installation instructions are included in this kit, be sure to give them to the customer.



Component	No.	Parts Name	Qty	Parts No.
	(1)	Right deflector B	1	—
	(2)	Left deflector B	1	—
	(3)	5 x 35 mm socket bolt	2	—
	(4)	Grommet	2	18357-MCG-000
	(5)	Flange collar	2	90122-463-770
	(6)	Collar	2	52161-MLC-D00

INSTALLATION

1.	Degrease as shown.
	

- Install the deflector B following the steps below.
1. Press the double-sided tape onto the front side cover.
The adhesive strength of the double-sided tape increases in proportion to the pressure applied. Therefore, press the double-sided tape with the fingertip of your thumb with a force of at least 5 kg (50 N) as a guide.
 2. Press the entire deflector B.
Using the method from step 1, gradually move your thumb's fingertip while uniformly pressing the double-sided tape across the entire surface of the deflector B to exert adhesive strength.
 3. Leave undisturbed for more than 24 hours after sticking.

ADHESIVE BACKING
Pull out while pressing on the deflector B.



3. Install the right deflector B in the same manner as the left side.